


FIRST ESTABLISH IF BRACELET IS 1, 2 OR 3 BELOW AND THEN PROCEED AS INDICATED

1. SLIDING CLASP

i) Insert fine tipped tool into hole in clasp.



ii) To open/close clasp, move the tool in the direction indicated.



iii) slide clasp along bracelet to desired position.




iv) When in selected position, locate tabs on the back of clasp into slots on the bracelet and snap down/close the clip [see procedure (ii)].

IMPORTANT

To avoid straining the clip do not use excessive pressure. If resistance is found when closing clip, the tabs are not located properly and should be re-located.

2. ADJUSTABLE CLASP


To set the bracelet to the required length, depress the end pin of the spring bar as indicated below using a pointed instrument (e.g. a pin) and relocate the spring bar in any one of the holes.



3. LINK ADJUSTMENT

Some of our bracelet models are now fitted with a multiple clasp system which is designed to make bracelet adjustment easier for you.

To reduce the size of the bracelet simply open and remove the adjustable clasp indicated as (A) on the diagram.



Some adjustable clasps can be finely adjusted by opening the clasp and re-locating into suitable clasp slot.

Note: Adjustable clasps will vary in style depending on the watch bracelet design.

If your adjustment requires specialist tools, we recommend visiting a reputable jeweller or watch specialist in your area. Please note that any damage caused by self-adjustment will not be covered under the guarantee, as it would be considered accidental damage.

Alternatively If you purchased your watch from a high street jeweller, you may also return it to the store for a bracelet adjustment service.

If you're still having issues, please visit your local jeweller to have this adjustment carried out.

CUSTOMER'S NAME

ADDRESS

.....

.....

..... POSTCODE

DAYTIME PHONE NO

BRACELET GAUGE



1. Place gauge around wrist.
2. Adjust to comfortable length on wrist.
3. Mark tape at required length.

DO NOT ATTEMPT TO ADJUST THE BRACELET YOURSELF BEYOND THE INSTRUCTIONS IN ITEMS 1, 2 AND 3 OVERLEAF. ANY DAMAGE CAUSED TO THE BRACELET WILL INVALIDATE THE MANUFACTURER'S GUARANTEE.